

DOOR SENSOR
 1-4-0101-0454



1. Contact Configuration: NO – normally open
2. Switching current: 500 mA
3. Switching voltage: max 200 V
4. Connection: screw
5. 1 door sensor to 1 WING EC controller

Example of connection:

